



SeaDek Application/ Installation Instructions

March 8, 2016

TOOLS:

1. Sharp razor knife
2. Ammonia based window cleaner (preferred) and Acetone
3. 1-Inch Masking Tape

VIDEOS OF INSTALLATION:

1. Watch a video demonstration of installation on our website at: www.seadek.com under the DIY section.
2. Scan QR Code for quick link to installation video

STORAGE:

1. SeaDek should be stored in a cool, dry, indoor location until installed on boat.

INSTALLATION LIMITATIONS:

1. Do NOT install SeaDek in temperatures below 60 degrees Fahrenheit.
2. Do NOT attempt to remove and adjust placement once pad is down.



PREPARATION:

1. Use an ammonia based cleaner followed by acetone on the surface area. Thoroughly clean the surface area where SeaDek will be applied.
2. Make sure all grease, adhesive, mold-release, wax and other substances are removed before installing the product. The area must be completely dry before applying pads.

INSTALLATION:

1. Before you peel back the adhesive backing, place the pads on the surface area to verify the fit and spacing in order to determine the exact location of the pad(s).
2. Turn pad over so that the adhesive backing is face up. With a sharp razor knife carefully cut the paper adhesive backing down the center at the shortest width. Be sure to completely cut through the adhesive backing but DO NOT cut into the pad.
3. Now peel back and fold the four corners of the paper backing.
4. Turn the pad back over and reposition it exactly where you want it installed.
5. Firmly secure one side of the pad to the surface area using 1-inch masking tape. Taping prevents the pad from moving.
6. Now lift up the side that is not taped down and pull up the folded corners to loosen the adhesive backing.
7. From the center working towards the outer edges, slowly and carefully peel the rest of the paper backing while applying the pad. Apply pressure to the pad to ensure there's a firm bond between the pad and the surface area.

DO NOT PULL OR STRETCH THE PAD(S)

8. Remove the masking tape from the other side of the pad and repeat step 7.
9. Firmly press down on all surface areas and edges of the pad to ensure there's uniform adhesion.

SCWake

4100 US Highway 52, New Trenton, IN 47035

Ph: 812-637-0262 / Fax: 855-SCWake-1

E-mail: Info@scwake.com